

# Straumann® Bone Level (BL) or Bone Level Tapered Implant (BLT) Impression Parts Flow Chart



## BL Implant Sizes

### Diameters

3.3 mm, 4.1 mm, 4.8 mm

### Lengths

8 mm, 10 mm, 12 mm, 14 mm

## BLT Implant Sizes

### Diameters


2.9 mm, 3.3 mm, 4.1 mm, 4.8 mm

### Lengths

8 mm, 10 mm, 12 mm, 14 mm, 16 mm, 18 mm

## Restorative platform of implant placed

2.9 mm 3.3 mm 4.1 mm 4.8 mm



**Tools needed for all Straumann restorations except LOCATOR® or Ball Attachment Overdentures:**

Straumann Torque Wrench and Straumann SCS Screwdriver



# Straumann® Tissue Level Impression Parts for Crowns Flow Chart



## Collar Types

### Standard (S):

2.8 mm smooth collar height

### Standard Plus (SP):

1.8 mm smooth collar height

## Platforms

Regular Neck (RN): 4.8 mm

Wide Neck (WN): 6.5 mm


## Diameters

3.3 mm, 4.1 mm, 4.8 mm

## Lengths

6 mm, 8 mm, 10 mm, 12 mm, 14 mm

**Restorative platform of implant placed**  
3.3 mm 4.1 mm 4.8 mm



## Tools needed for all Straumann restorations except LOCATOR® or Ball Attachment Overdentures:

Straumann Torque Wrench and Straumann SCS Screwdriver or Solid Abutment Driver (RN only)

